

1"

This pattern is to scale. Printer setting should be "Actual size" / 100%. If your printer allows, choose "Boarderless printing" so the pattern's lines print right to the edge of the paper. If your printer doesn't have that option, you'll have a white space along the edge of your paper, but cut your pattern piece as though the cut-line goes right to the edge.

*Check scale  
before cutting*

## TOP LEFT PATTERN PIECE

Placement of the magnetic snap on the  back of the lunch bag

## PAPER BAG STYLE LUNCH BAG

- Cut 2 pieces from fabric (for front & back)
- Cut 2 pieces from food-safe PUL

If cutting fabric on the fold:

- Cut 1 piece from fabric
- Cut 1 piece from food-safe PUL

For magnetic snap closure

- Cut 2 pieces of fusible interfacing  $1/2" \times 1/2"$

$1/2"$  seam allowance

Placement of the magnetic snap on the  front of the lunch bag

TOP RIGHT PATTERN PIECE



## BOTTOM LEFT PATTERN PIECE

*Gathered Seams*  
FROM PATTERN TO PROFIT



PLACE ON FOLD



If cutting fabric on the fold

If cutting from two pieces of fabric

# BOTTOM RIGHT PATTERN PIECE



PLACE ON FOLD

cut pattern piece along this line



cut pattern piece along this line